Ice Maker

The kitchen refrigerator is equipped with an Ice Maker. Ice is dispensed via the controls on the front of the refrigerator as below:



To turn the Ice Maker on (or off) simply slide the switch located inside the Freezer as below:

Slide out cover / tray (just pulls out)



Slide ON/OFF switch as required

