

A

Alarm Clocks

Each bedroom is equipped with a Radio Alarm.

To set the correct time if not done so already.

1. Hold down Set Time button until display flashes.
2. Press the Hour and Minute buttons to set the correct time. Not the PM light on the front to ensure you have AM/PM correct,
3. Press Set Time again to hold the time or it will automatically hold in a few seconds.



Set the Alarm as follows:

1. Press and Hold AL1 until the display flashes (you can also repeat the same procedure using AL2 for a second alarm call)
2. Set the Alarm time using the Hour and Minute buttons (be sure to check for AM/PM as before) then press AL1 to set.
3. Check on the front whether the alarm is set to Radio or Chime. To change between Radio and Chime press AL1 (just press don't hold it down)

