

B

Blender

A multi purpose food blender is provided in the kitchen for your use.

To remove the blender jug simply turn the jug clockwise and to replace simply insert into the guides and turn anti-clockwise to lock into position.

Speed settings are self explanatory.

There is also a Margaritaville Blender see M section for more details.