

# B

## Blinds


The home is fitted with horizontal blinds on all windows and vertical blinds on the slider / patio door. Please observe the following instructions for using the blinds, failure to do so may result in damage with may result in you being charged against your security deposit.

To open or close the patio slider blinds you can use either of the scene controllers to the left or right of the patio slider or the sitting room tablet by pressing on the Blinds button from the home screen.



To Open the Blinds using the Scene Controller to the left of the Patio Slider simply press button 5 or button 6 to close the blinds. BE PATIENT it can take up to 10 seconds to react.

## Scene Controller - Patio Slider Left



Button	Function
1.	Patio Seating Light
2.	Patio Dining Light
3.	Patio Seating Fan
4.	Patio Dining Fan
5.	Open Blinds Be patient it can take up to 10 secs
6.	Close Blinds Be patient it can take up to 10 secs
7.	Sitting Room Lights

To Open and Close the blinds using the Scene Controller to the right of the patio slider simply press button 1.